



Proper Fit: The proper fit of the nylon collar, working battery, functioning fence and correct programming is the difference between a dog being 100% contained and bolting through the fence. The collar should be fitted right behind the ears and snug for proper fit.

Measuring Correct Size: Do not measure your dog's walking collar unless it is a snug fit. Most dog owners have walking collars that dogs can pull out of if they make an effort to do so. The Pet Stop Collar should ride high on the dog's neck, not down at the base of their neck.

Measure with a Tailor's Tape to get the most accurate length.

- How long is the collar you need in inches?

Measure from end of clip to end of clip and then choose the appropriate size collar listed below.

Ex Small: adjusts 8 to 11

Small: adjusts 10 to 13 inches

Medium: adjusts 13 to 17 inches

Large: adjusts 17 to 23 inches

- What color would you like?

Black, red, blue, green, purple, pink

- Would you like light weight or heavy duty?

Light weight: $\frac{3}{4}$ Inch

Heavy weight: 1 Inch